

By default your device updates automatically to the newest available firmware. The following information only affects you if you choose to do so manually:

* If your device uses a firmware version that starts with V9.00.xxxxxx then first update to V9.01.000051 and then to the latest firmware version.

* If V9.01.000051 (or newer) is already installed, you can update directly to the latest firmware.

* You can find your currently installed firmware version on the initial (“Status”) web page of your device in the left bottom “Device information” field.